

3ft&6ft Propane Grill Operating Instructions

Grill Set up

This Grill is designed FOR OUTDOOR USE ONLY.

1. Thread the Acme Nut Connector snugly into the main cylinder valve by turning clockwise (to the right) Prior to opening main cylinder valve, and lighting grill, place all control knobs in the "CLOSED" position (turned to the left).
2. Open main cylinder valve.
3. Remove cooking grate for easier access to burner tube.
4. Hold a lit butane gun next to a burner and turn the burner control knob to "OPEN" (pointing at you). The burner will ignite instantly. The second burner in each section will instantly light by simply turning it on. Since each section is ignited separately, only light the section required. Once burners are lit, adjust the control knobs to desired temperature.
5. When finished cooking close all control knobs, close main cylinder valve and disconnect propane cylinder.
6. Clean grates with non-metallic pad (like Scotch-Brite) while grates are still hot.

Propane Safety

1. Never use or store cylinders indoors.
2. Keep main cylinder valve securely closed when not in use:
3. Propane tank valves are designed to work completely open and/or completely closed. Never just crack the valve.
4. Always position the LP cylinder so that the connection between the valves and the regulator will not cause sharp bends in the hose.

DISCONNECTING AND TRANSPORTING CYLINDERS

1. Turn off all control knobs and close the main cylinder valve. Disconnect cylinder from grill before transport
2. Always transport and store cylinders in a secured and upright position
3. Never keep propane cylinders in a hot car or truck. Heat could cause the relief valve to discharge propane and create a dangerous situation.